METHOD OF USAGE

• Plug the wire in to the plug set, the power indicator light flash, then into a standby situation



• diagram of pluging the power



• power switch

 Overturn frame	• According to your requirement, lift the base frame by hand, the front part will lift forward, the angle is 20 degree.
On/off	• Press On/ off button, entering the massager works. Depend on your requirement, please choose different massage modes and speed on Mode and Speed button. You open and close heating therapy by pressing Heating therapy key.
Stop	• Press Stop button, shut off the function of massage and heating therapy. The power light is flashing and enter standby mode.

• Auto shut-off feature after the massager has been in use for 15 minutes. The power light is flashing and enter standby mode.



• Diagram Of Turn Off The Power

Note

1.Please switch off power and unplug power plug if not use frequently .
2.No standing during massage and before or after using to avoid damage to the machine.

METHOD OF USAGE

Correct massage method

• According to individual massage demand, appropriately adjust upper section to some angle to massage knee and calf.(picture 1)

• According to individual massage demand, appropriately adjust upper section to a best angle to massage calf and thigh .(picture 2)

• According to different massage part, turn over upper section by 110° to massage knee.(picture 3)



(picture 1)



(picture 2)



(picture 3)

PRODUCT SPECIFICATION

Name	Teo-tier Leg Beautician With Rollor
Model	C30
Rated Voltage	110-120V~ 60Hz ▭
	220-240V~ 50Hz/60Hz ▭
Rated Power	110W
Rated Working Time	15Minutes
Structure Safety	▣

Note: our copmany reserved the rights of product's design and explaination.
Please check with us before order, we may change outlook design without notice.

C30 TEO-TIER

LEG BEAUTICIAN WITH ROLLOR

operation instructions





SAVE THESE INSTRUCTIONS

IMPORTANT SAFETY WARNING

1、SafetyWarning
- Please use this product according to this Manual
- Please ensure that the mains power is suitable for this product，do not use this product if its casing or mains cable is damaged
- Do not allow any foreign matter to enter the clearance between the massagehead and the casing
- Do not allow the product to come into contact with water so as to avoid anypossible accidents that may result from a short circuit
- Please disconnect the product from the mains supply after use or before cleaningto avoid damage to the equipment or personal injury
- Do not plug or unplug this product when your hands are wet
- Do not pull the cable when plugging orunplugging, and not available strong force
- Do not damage the cable or change the circuit of the product
- Please cease using this product in case of a power cut in order to avoid anybody injury upon sudden power resumption
- Do not use any spare parts and attachments other than those recommended
- Do not use the appliance in outdoor
- Do not use this product with too much force so as to avoid injury
- Do not use this product within an hour after a meal
- Please stop using this product and consult your local supplier if you noticeanything abnormal with the product during use
- Please stop using this product and consult your doctor for adviceif you noticeanything abnormal with the product during use.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.Children should be supervised to ensure that they do not play with the appliance.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

2.Working Environment
- Do not use this product in a highly humid environment such as a bathroom
- Do not use this product immediately after there has been a sharp change in theenvironmental temperature
- Do not use this product in an environment where there are lots of dust orcorrosive gases

3、People That Should Not Use This Product
- Women that are pregnant or menstruating
- People with contagious skin conditions
- Patients with osteoporosis
- Patients with heart diseases and with electronic medical instruments like a heartpacemaker

IMPORTANT SAFETY WARNING

- People in a high fever
- Those who are injured or suffering from anybody surface disease
- Children under 14-year old or people mentally unbalanced without being Supervisedare not allowed to use this machine
- Those who need to rest according to a doctor's advice or those who do not feelwell
- Those who are wet
- Those are under the influence of alcohol or feeling unwell
- Please according to your doctor's advice if you have had an operation recently
- The appliance has a heated surface. Persons insensitive to heat must be careful when using the appliance.

FUNCTION

1. The new foot massage with full air bag massage, designed with two sections, up and down section with overturn function, novel appearance, fashionable design.
2. Total with 30 air bags, kneading with thigh, calf, instep affective, the 3 active rollers on foot can massage the muscle on foot effectively, stimulating the reflex point on foot.
3. The organic combination of kneading and rolling wheel, give you a relaxingmassage experience, meanwhile, achieve beauty legandbeneficial reflex
4. With carbon fiber heat on thigh, ankle, has warm therapy effect.
5. The up and down section can turn 110 degree, with handle overturn frame in the bottom, the angle is 20 degree, can massage your knee conveniently when you lift it



Calf turnover



Overturn frame


Back Wheel

6. With base caster, can move easily, the noise of the product less than 45db
7. With three individuation air massage models, three intensity options, three roller massage model, in automatically model, the roller change one model one minute, manual model, jump out automatically to automatic model
8. After 15 minutes massage, the machine is shut off automatically.
9. The kneading cover with zip can be cleaned easily so as to keep massager neat and tidy.

COMPONENT NAME AND FUNCTION

